

Reset Care

Guidelines to keeping your product in the best condition.



Framework

Mix mild soap and warm water together. Dampen a lint-free cloth lightly in the mixture. Clean the framework with the cloth. Use another dry, lint-free cloth to dry the area. Repeat as needed.

Mesh

As needed, clean mesh mixing mild soap and warm water together. Dampen a lint-free cloth lightly in the mixture. Clean the mesh with the cloth. Use another dry, lint-free cloth to dry the area. Repeat as needed.

Fabric

As needed, clean seat fabric with water-based foam or upholstery cleaner or dry cleaning solvents. Do not saturate with liquids or get furniture wet. Vacuum regularly using a proper upholstery attachment.

Casters

Once a month, gently flip your chair over and carefully use tweezers to remove hair & debris out of the creases of each caster. Use a lint-free cloth with your preferred cleaning agent and clean the caster thoroughly. Thoroughly dry the caster with another lint-free cloth.



We're here to help.

Call us at 877-211-5814 or email us at customer care@ergify.com for support.

